

Perfect fit means great protection



1. Check the mask. Sling the neck strap over your head before fitting it to your face.

2. Start with the chin, then cup the mask over your mouth and nose.

3. Pull the head strap over your head and position it on the crest of your head. Never fit the harness over a cap or a hard hat.

Tighten the head harness at the buckle until the mask is tight but comfortable against your face.

4. Pull the bottom straps outwards a few times to even out the tension and to make sure the top head strap is tight and secure.

Negative user seal check

1
Ensure that the mask seals effectively by using the air-tight testing disc SR 322.

2
Place the disc inside the pre-filter holder and attach it to the main filter.

3
Breathe in deeply and hold your breath. If the seal is good, the mask will press against your face.

4
Inadequate fit may be caused by beard growth, stubble, deep facial furrows or unusual face size.

5
Leakage may also occur if the exhalation membranes are soiled or defective.

N.B.

The disc is only used during the fit test, and should be removed immediately after each test.



Sundström 

www.srsafety.com