



DeskTop Model Calculators – Battery Replacement Instructions

Towards the top of the back of your calculator, you will find a total of four screws. The upper two screws are only for the display. Do not remove them. The lower two of the four screws are what hold the calculator together. Go ahead and remove them. Once you have removed the two lower screws, you are ready to pull the two halves of the calculator apart. There are two methods for separating the two halves. The first is to hold the bottom of the calculator with one hand and use the other hand to pull the top half away while working it from side-to-side carefully.

Some users have difficulty grasping the calculator with one hand. If pulling the two halves apart by hand proves too difficult, use a small flat tool (flat-blade screwdriver, etc.) and carefully work it around the seam between the two halves until they are apart. Just remember to be very careful when using this method because a metal tool could scratch the plastic. Also, do not push the tool more than one-quarter of an inch into the calculator or you may risk damaging an internal component. Once the two halves are apart, remove the battery from within its holder and replace it with the new battery. Make sure the positive side is facing out (towards you).

T-BatRep-DT-10_06

Calculated Industries/Calculated.com ("CI") does not warrant the accuracy or completeness of the information, including calculations/keystrokes, text, graphics or other items that CI provides. CI is not responsible for any human or mechanical errors or omissions and will not be held responsible for any loss, damage or inconvenience caused as a result of any inaccuracy or error. Under no circumstance will CI be liable to any person or business entity for any direct, indirect, special, incidental, consequential or other damages based on any calculation or information CI provides.