

SKATEPLATE® SIDEWINDER FITS THE FOLLOWING SAW MODELS

SKATEPLATE® SIDEWINDER SE AJUSTA A LOS SIGUIENTES MODELOS DE SIERRA:

SKATEPLATE® SIDEWINDER (À ENTRAÎNEMENT DIRECT) S'ADAPTE AUX MODÈLES DE SCIE SUIVANTS:

SAW BRAND	SAW MODELS
MODELO DE SIERRA MODÈLE DE LA SCIE	MODELO DE SIERRA MODÈLE DE LA SCIE
BOSCH	CS10
BOSTICH	BTE300K
CRAFTSMAN	10870 27311
DEWALT	DWE575 DWE575S
HITACHI	C7SB2 C7BMR C7ST
MAKITA	5007F 5007FA 5007MG/MGA 5007NK 5008MGA 5740NB
MILWAUKEE	6390-20, 6390-21, 6394-21
PORTER CABLE	PC13CSL* PC13CSLK* PC15TCS PC15TCSMK PTC5M
RIDGID	R32022 R3205 R32021
SKIL	5080-01* 5180-01* 5280-01 5380-01* 5480-00* 5480-01* 5580-00* 5582-00* 5585* 5587-01 HD5687 5680-01 5680-02 SPT67WM-22 SPT67FMD-22
STANLEY FATMAX	FME300K-QS , FME301

*Indicates provided spacers required

SKATEPLATE® WORMDRIVE FITS THE FOLLOWING SAW MODELS:

SAW BRAND	SAW MODELS
MARCA DE SIERRA MODELO DE SIERRA MARQUE DE LA SCIE	MODELO DE SIERRA MODÈLE DE LA SCIE
BOSCH	CS41 MAG 1677M
DEWALT	DWS535 DWS535T
MAKITA	377MG 5477NB*
RIDGID	R3210-1 R32102
SKIL	SHD77 SHD77M SHD77M-02 SHF77-72 SHD77M-72 MAG77LT MAG77LT-72 SHF77-73 SHD77M-73 MAG77-75

* REQUIRES PROVIDED SPACER

* REQUIERE EL USO DEL SEPARADOR SUMINISTRADO CON EL PRODUCTO

* UTILISER L'ENTRETOISE FOURNIE