

BIG BED[®] ***JUNIOR*** ***'TAILGATE EXTENDER'***


**To avoid personal injury and/or property damage, please read and follow
ALL instructions before assembling and operating.**

1. Never overload Big Bed[®] Junior. Maximum capacity is 350 lb. (Evenly distributed load).
2. A **2" receiver** is required to use the Big Bed Junior. Refer to manufacturer's hitch capacity.
3. Long and heavy loads reduce control of steering, and braking capability. Use extreme caution when hauling longer loads. Test control before accelerating.
4. The load must rest and extend beyond the horizontal support of the apparatus.
5. Secure the load by utilizing the tie-down hook holes with weight appropriate strap. Fasten a red flag to mark the end of the load.
6. Do not leave the Big Bed in the receiver unless in use.
7. Check Government regulations for specific laws in your province or state on the allowable overhang out the back of your vehicle.
8. Proper use of this product is critical to safety, and beyond the control of Erickson Manufacturing Ltd. Erickson Manufacturing Ltd. neither guarantees nor is liable for any damage resulting from improper use. The liability of this product is limited to its purchase price if it proves to be defective in material and/or workmanship.

Usage

Ideal for short-bed trucks, SUVs, vans, rhino/gators, and all other vehicles capable of hauling a load. We recommend using your new Big Bed for the following :


- Lumber
- Canoes
- Extension ladders
- Oversized sheets of plywood and drywall
- Utilize it as an extended workspace/bench
- Throw a tailgate party
- Create additional space for your hunting gear and supplies



The extender can be assembled two different ways, respectively with the long end or short the end of L-extension (2) connecting to the T-support(1)


ASSEMBLY 1,

1. With the short end of the L-extension (2) facing up, slide it into the T-support (1);
2. The T-support (1) has 5 holes to change the height. Line up the hole on the T-support (1) with the desired hole on the L-extension (2);
3. Insert the pin lock (3) through the T-support (1) and the L-extension (2), secure with 3.8 cotter pin (4).
4. Pull on the L-extension (2) and the T-support(1) to make sure they are properly locked in place.



ASSEMBLY 2

Assembly 2 are all same with that of assembly 1 expect that we change the connection side of L-extension (2) to be the long end for the T-support(1).

**Part List**

Part#	Description	Q'ty	Part#	Description	Q'ty
1	T-support	1	3	16 Pin	1
2	L-extension	1	4	3.8 Clip	1

Warranty

Warranty Exclusions

This warranty does not cover the following repairs and equipment:

Normal Wear

This warranty does not cover the repair when use has exhausted the life of a part or the equipment as a whole.

Installation, Use and Maintenance

This warranty will not apply to parts and/or labor if this product is deemed to have been misused, neglected, involved in an accident, abused, loaded beyond specifications, modified, or installed improperly. Normal maintenance is not covered by this warranty.

Other Exclusions

This warranty excludes:

- Cosmetic defect such as paint, decal etc.
- Wear items
- Accessory parts
- Failures due to acts of God and other force majeure events beyond the manufacturer's control.
- Problems caused by parts that are not Erickson Manufacturing Ltd. parts.

Limits of implied Warranty and Consequential Damage

Erickson Manufacturing Ltd. disclaims any obligation to cover any loss time, use of this product, freight, or any incidental or consequential claim by anyone from using this product. **THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** A unit provided as exchange will be subject to the warranty of the original unit. The length of the warranty governing the exchanged unit will remain calculated by reference to the purchase date of the original unit. This warranty gives you certain legal rights which may change from state to state. Your state and/or province may also have other rights you may be entitled to that are not listed within this warranty.

Contact Information

Marine City, Michigan 48039

Thamesville, Ontario N0P 2K0

Toll Free: 1-888-546-4668